



Wireless Temperature and Humidity Sensor with Display Model: THGR122N

Wireless Temperature and Humidity Sensor Model: THGN122N

USER MANUAL



EN

## INTRODUCTION

Thank you for selecting the Oregon Scientific™ remote sensor (THGR122N / THGN122N). This product is compatible with various wireless weather station products.

Keep this manual handy as you use your new product. It contains practical step-by-step instructions, as well as technical specifications and warnings you should know about.

## PRODUCT OVERVIEW



## GETTING STARTED

To set up the sensor:

1. Open the remote sensor battery compartment with a small Phillips screwdriver.

2. Insert the batteries, matching the polarity (+ and -).



3. Set the channel. If you are using more than one sensor, select a different channel for each sensor.

4. Place the sensor near the main unit. Press **RESET** on the sensor. Then, press the appropriate main unit button (as specified in the main unit manual) to initiate signal sending between the sensor and the main unit. The reception icon on the main unit will blink for approximately 3 minutes while it is searching for the sensor.


5. Close the sensor battery compartment.

6. Secure the sensor in the desired location using the wall mount or table stand.

**NOTE** shows on the THGR122N when the batteries are low.

**NOTE** Install batteries in the remote sensor before the main unit. Press **RESET** after each battery change. Do not use rechargeable batteries. We recommend that you use alkaline batteries with this product for longer usage and lithium batteries in temperatures below freezing.

**COUNTRIES RTTE APPROVAL COMPLIED**  
All EU countries, Switzerland and Norway



## ABOUT OREGON SCIENTIFIC

Visit our website ([www.oregonscientific.com](http://www.oregonscientific.com)) to learn more about Oregon Scientific products such as digital cameras, MP3 players, children's electronic learning products and games, projection clocks, health and fitness gear, weather stations, and digital and conference phones. The website also includes contact information for our Customer Care department in case you need to reach us, as well as frequently asked questions and customer downloads.

We hope you will find all the information you need on our website, however if you're in the US and would like to contact the Oregon Scientific Customer Care department directly, please visit: [www2.oregonscientific.com/service/support](http://www2.oregonscientific.com/service/support)

OR

Call 1-800-853-8883.

For international inquiries, please visit: [www2.oregonscientific.com/about/international](http://www2.oregonscientific.com/about/international)

## INDUSTRY CANADA STATEMENT

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

IC: 3277A-TX-H222NR

## FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**WARNING** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.  
• Increase the separation between the equipment and receiver.  
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
• Due to printing limitations, the displays shown in this manual are not the actual displays.  
• The contents of this manual may not be reproduced without the permission of the manufacturer.  
• Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

**NOTE** The technical specifications for this product and the contents of the user manual are subject to change without notice.

## DECLARATION OF CONFORMITY

The following information is not to be used as contact for support or sales. Please call our customer service number (listed on our website at [www.oregonscientific.com](http://www.oregonscientific.com)) or, on the warranty card for this product) for all inquiries instead.

## TROUBLESHOOTING

PROBLEMA	SINTOMO	REMEDIY
Remote sensor	Cannot locate remote sensor	Check batteries Check location
Cannot change channel	Only one sensor is working	Check sensors. Only one sensor is working
Data does not match main unit	Initiate a manual sensor search	

## SPECIFICATIONS

L x W x H	92x60x20 mm (3.6 x 2.4 x 0.79 inches)
Weight	62 grams (2.22 ounces)
Humidity range	5% to 95%
Humidity resolution	1%
Temperature unit	°C (°F)
Temperature outdoor range	-30°C (-22°F) to 60°C (140°F)
Temperature resolution	0.1°C (0.2°F)
RF frequency	433 MHz
Range	30 meters (98 feet)
Transmission	Every 40 seconds
Channel No.	1 - 3
Batteries	2 x UM-3 (AAA) 1.5V

**NOTE** It is recommended that you use alkaline batteries with this product for longer usage and lithium batteries in temperatures below freezing.

**EU-DECLARATION OF CONFORMITY**  
Hereby, Oregon Scientific, declares that this Remote Sensor (model THGR122N / THGN122N) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

A copy of the signed and dated Declaration of Conformity is available on request via our Oregon Scientific Customer Service.



**COUNTRIES RTTE APPROVAL COMPLIED**  
All EU countries, Switzerland and Norway

## Sensore senza fili di temperatura e umidità

Modello: THGR122N

## Sensore senza fili di temperatura e umidità

Modello: THGN122N

## MANUALE PER L'UTENTE


### IT

#### INTRODUZIONE

Grazie per aver scelto questo sensore senza fili di temperatura ed umidità di Oregon Scientific™ (THGR122N / THGN122N). Questo prodotto è compatibile con diverse stazioni meteorologiche.

Consigliarsi di tenere questo manuale a portata di mano durante l'utilizzo del prodotto. Il manuale contiene pratiche istruzioni dettagliate, dati tecnici e avvertenze che è necessario conoscere.

#### PANORAMICA



#### 1.Display LCD (il modello THGN122N non dispone di display LCD):

Indica il numero del canale

Le rilevazioni di temperatura ed umidità

#### 2.Indicatore LED di stato




#### 1. Foro per fissaggio a parete

#### 2. Foro RESET

#### 3. Selettori del canale (CHANNEL)

#### 4. Vano batterie




#### OPERAZIONI PRELIMINARI

##### Per l'impostazione del sensore:

1. Con un piccolo cacciavite, aprire il vano batterie del sensore remoto.

2. Inserire le batterie, rispettando la polarità indicata (+ -).



#### 3. Impostare il canale. In caso si utilizzi più di un sensore, selezionare un canale diverso per ciascuno di essi.

#### 4. Collegare il sensore vicino all'unità principale. Premere RESET sul sensore. Successivamente, premere il pulsante corrispondente del canale (come specificato sul manuale della stessa) per avviare la sincronizzazione tra il sensore e l'unità principale. Durante la ricerca del sensore, l'icona di ricezione dell'unità principale lampeggerà per circa 3 minuti.

5. Chiudere il vano batterie del sensore.

6. Collegare il sensore nella posizione desiderata mediante il foro per fissaggio a parete o con il supporto da tavolo.

**NOTA** viene visualizzato sul modello THGR122N quando le batterie sono esaurite.

**NOTA** Inserire le batterie nel sensore remoto dopo averle sostituite. Non utilizzare batterie ricaricabili. Per un uso prolungato del prodotto, si consiglia di utilizzare batterie alcaline, mentre in caso di temperature inferiori allo zero si consiglia l'uso di batterie al litio.

#### RISOLUZIONE DEI PROBLEMI

#### PROBLEMA

#### SINTOMO

#### SOLUZIONE

Sensore

Impossibile localizzare

Il sensore remoto

Controllare la posizione del sensore

Impossibile cambiare il canale

Il sensore


Funziona solo un sensore

I dati non corrispondono all'unità principale

Avviare la ricerca manuale del sensore

Le donne ne corrispondono all'appareil principal

Initiez une recherche manuelle du capteur.



## Capteur de Température et d'Humidité Sans Fil avec Ecran LCD

Modèle : THGR122N

## Capteur de Température et d'Humidité Sans Fil

Modèle : THGN122N

## MANUEL DE L'UTILISATEUR

### FR

#### INTRODUCTION

Merci d'avoir sélectionné ce Capteur à Distance de Oregon Scientific™ (modèles THGR122N / THGN122N). Ce produit est compatible avec plusieurs stations météorologiques sans fil.

Veuillez conserver ce manuel pour toutes références ultérieures. Il contient toutes les instructions pratiques, les caractéristiques techniques et les avertissements à prendre en compte.

#### Pour obtenir des meilleurs résultats :

- Positionner le capteur au rapproche de la lumière solaire directe et l'humidité.
- Ne placez pas le capteur à plus de 30 mètres (100 pieds) de l'appareil principal (intérieur).

• Positionnez le capteur de manière à ce qu'il soit face à l'appareil principal (intérieur), minimisant ainsi les obstructions causées par les portes, murs et meubles.

• Placez le capteur directement vers le ciel, éloigné des objets métalliques et électroniques.

• Positionnez le capteur à proximité de l'appareil principal pendant les mois d'hiver puisque le gel peut endommager le fonctionnement des piles et la transmission du signal.

• Pour obtenir des meilleurs résultats :

- Positionnez le capteur à distance de la base de l'appareil.
- Ne placez pas le capteur à plus de 30 mètres (100 pieds) de l'appareil principal (intérieur).

• Positionnez le capteur de manière à ce qu'il soit face à l'appareil principal (intérieur), minimisant ainsi les obstructions causées par les portes, murs et meubles.

• Placez le capteur directement vers le ciel, éloigné des objets métalliques et électroniques.

• Positionnez le capteur à proximité de l'appareil principal pendant les mois d'hiver puisque le gel peut endommager le fonctionnement des piles et la transmission du signal.

• Pour obtenir des meilleurs résultats :

- Positionnez le capteur à distance de la base de l'appareil.
- Ne placez pas le capteur à plus de 30 mètres (100 pieds) de l'appareil principal (intérieur).

